





NOTE 2

110VAC LUBE PUMP
Wire 110H-126 BLK connects from TB1/2B to RELAY BOARD/OUT2 COM.
Wire 110H-127 BLK connects to RELAY BOARD/OUT2 NO.
Wire 110N-128 WHT connects to TB1/5B.
Wire GND-4 GRN connects to TB1/9B.
Wires are 18 AWG

220VAC LUBE PUMP
220-226 BLK connects from F3/LOAD to RELAY BOARD/OUT2 COM
Wire 220-227 BLK connects to RELAY BOARD/OUT2 NO.
Wire 220-228 WHT connects to F4/LOAD.
Wire GND-4 GRN connects to TB1/9B.
Wires are 14 AWG

NOTE 4

WIRES AND CIRCUIT BREAKERS MUST BE RATED FOR THE CURRENT RATING OF THE DEVICES USED. REFER TO OWNERS MANUAL FOR SPECIFIED WIRE GAUGE AND CURRENT CAPACITY.