

PART	(MFG PN:)	LOCATION
CB1	(NB1-D10-1P)	C3
CB2	(NB1-D6-1P)	C3
CB3	(SEE NOTE 4)	C3
CB4,CB7	(NB1-D10-2P)	D3
CB5	(SEE NOTE 4)	D3
CB6	(NB1-D10-3P)	D3
CB8	(SEE NOTE 4)	D3
CNT1A,CNT1B	(LC1D7408B7)	B2,B3
CNT2	(LC1K0610B7)	B3
DISCONNECT	(OT100F3)	B1
DOOR FAN		H4
E-STOP CONNECTOR		B5
E-STOP CON. PENDANT		E6
E-STOP SWITCH		B5
E-STOP SWITCH CONSOLE		B6
FLOOD PUMP MOTOR		A3
GROUND LUG		B1
GROUND STRIP		B4
GEAR RANGE SWITCHES		A2
INVERTER		A1
OPERATOR CONTROL PANEL		E6
LIMIT SWITCHES		A4
LIMIT SWITCH OPTIONS		G6
LUBE PUMP		A3
MIST		A3
MPG CABLE		E6,F6
NOTE 1		A2
NOTE 2		A3
NOTE 3		B2
NOTE 4		C1
NUC	(PN:8520)	B6
OAK	(PN:13135)	E2,F4
OCR2	(LR2K0310)	B3
PC	(PN:11084)	B6,C6
PLCADD1616	(PN:11025)	H1,H2
PROBE CABLE	(PN:11211)	F6
PS1	(RQ-650)	E4
PS2	(S-25-24)	E5
PS3	(RT-50B)	E4
SERVO DRIVES		F4-G5
SNUBBER FOR CNT1	(LA04RCE)	B2
SNUBBER FOR CNT2	(LA4KE1B)	B3
SPINDLE COOLING FAN		A2
SPINDLE MOTOR		A1
T1	(4953)	C1-D2
TB1		D2,D3
WORK LIGHT		A2
X-AXIS BRAKE CONNECTOR		E5