Contour ShuttleXpress for use with CENTROID CNC1 2 software

Budget 4-axis USB Jog Controller with an "MPG like" Inner wheel and a continuous jog Outer wheel



7.) The Outer Jog Wheel jogs any axis continuously. The further you rotate the wheel the faster the axis jogs. Jog speed override increments are 10%, 35%, 75%, 100%, 135%, 175% and 200% of the set fast or slow jog value. Feed rate override percentage returns to 100% when the outer wheel returns to center. (Note: If you have parameter 39 set to limit the feed rate override percentage, the outer wheel will not exceed that limit)

6.) The Inner Jog Wheel jogs an axis a set amount determined by the x1,x-10,x100 increment selection. Each detent of the wheel moves a specified amount (like an mpg).

For those on a budget the ShuttleXpress is perfect for all types of Mills, Lathes, Routers and other specialty CNC machines. Jog any axis incrementally with rotation of the inner wheel Jog any axis continuously and easily vary the speed of the jogging with the Outer Wheel. Simple inexpensive machine tool jogging controller the Contour ShuttleXpress is Plug and Play with Centroid CNC12 Pro CNC software, Simply run the Contour setup software and install the included Centroid CNC preference file, select "Yes" to ShuttleXpress in the Centroid Setup Wizard and you are good to go. Visit this page for installation video. https://www.centroidcnc.com/centroid_diy/contour_shuttle.html

- 4 axis machine tool jog controller
- Corded USB device
- Preprogrammed Centroid provided drivers
- Free Tech Support via CNC Forum

- Smooth motion
- Inexpensive
- Simple setup and installation
- Requires Centroid CNC12 v4.12+ (or higher)







https://www.centroidcnc.com/centroid diy/wireless mpg control pendant.html

WMPG-4 Kit for use with Acorn CNC systems

WMPG-4 Kit for use with Acorn CNC systems

- WMPG-4 Wireless MPG pendant
- USB Wireless Transmitter / Receiver
- Mounting Bracket
- Requires Centroid CNC12 Pro or Dig v4.12+ (or higher)
- CENTROID part # 8928







